

INSTALLATION INSTRUCTIONS

MERCURY MOUNTAINEER (1996-2001)
 FORD RANGER (1995-2007) FORD EXPLORER (1995-2001)
 MAZDA B2300 (1995-2007), MAZDA B2500 (1998-2001)
 MAZDA B3000, B4000 PICKUP (1995-2007)
 FORD SPORT TRAK (2001-2005),



NOTE: READ INSTRUCTIONS COMPLETELY BEFORE INSTALLING THIS BRACKETRON PHONE MOUNT.

All instructions are written from the drivers seat position looking forward at the vehicle dash. We advise caution whenever your removing or handling plastic parts of a vehicles dash. **WARNING:** Unnecessary force or pressure can cause pieces to crack or break.

Logo and part number will be right side up and readable when installed.

TOOLS NEEDED: 9/32" socket & driver, Ford DIN tools, #2 Phillips screwdriver, 5/64" drill bit, drill.

PARTS INCLUDED: One phone mount, two (2) #8x3/8" screws, instructions.

LOCATION OF MOUNT: To the right of the climate control unit



Step 1.

Locate four small holes on the face of the radio. Insert the (Ford Radio Removal DIN Tools) into these holes until you hear and feel a light click. Press outward on the DIN tools while at the same time pulling on them to slide the radio out of its cavity. Disconnect any wiring to the radio and set it aside in a safe place.

Step 2.

Locate two (2) 9/32" hex head screws just above the climate control. Remove these screws with the 9/32" socket and driver. Place the screws in a safe place. Grasp the trim bezel that surrounds both the radio and climate control in the upper right corner. **Carefully** use your fingers to grab and pull the bezel toward you releasing the top right clip. Perform this same action in all four (4) corners of the bezel releasing the remaining three (3) clips. When the bezel is loose, let it hang out of the way or prop it out of the way just enough to get to the climate control. **Note:** Be careful not to scratch the dash.



Step 3.

Locate the four (4) screws that hold the climate control in place. Use the 9/32" socket and driver to remove these screws. Set the screws aside. Carefully slide the climate control out enough to get the **Custom Bezel Mount** behind the right side of the climate control. Align the holes in the **Custom Bezel Mount** with the mounting holes for the climate control. Slide the climate control back into place. Replace the four (4) mounting screws and tighten them down. Locate two (2) holes in the **Custom Bezel Mount** just to the right of the climate control. Use these holes as a guide and carefully drill two (2) pilot holes using the 5/64" drill bit and drill. **Carefully** point the drill at an angle and make sure not to come in contact with the climate control, this will prevent damage. Insert the two (2) screws provided and tighten them with the #2 Phillips screwdriver.



Step 4.

Reinstall the dash trim bezel and radio in reverse order, secure all clips, screws and wiring. Install any **Bracketron** phone holder or Amps compatible device to your **Custom Bezel Mount**.

Your installation is complete.

© Bracketron Inc., 2007. All rights reserved.

The information in this document is subject to change without notice. **Bracketron Inc.** assumes no responsibility for any errors that may appear in this document nor do we assume any liability in connection with its use. This supersedes and voids all previous literature. Please contact the sales department for additional information.

Bracketron Inc will not be responsible or liable for damage to vehicles in the installation and or removal of this **Bracketron Inc** mount.

Bracketron Inc will not be liable for personal injuries or damage to property resulting from a motor vehicle accident and or improper installation of this **Bracketron Inc** mount.

Bracketron Inc 5249 West 73rd Street, Suite G, Edina, MN 55439, Ph: 651-952-746-7775 Fax: 1-800-660-1784 Toll Free: 1-866-237-4443

Web Address: www.bracketron.com