

INSTALLATION INSTRUCTIONS

VOLKSWAGEN PASSAT (2000-2005)



NOTE: READ INSTRUCTIONS COMPLETELY BEFORE INSTALLING THIS BRACKETRON PHONE MOUNT.

All instructions are written from the drivers seat position looking forward at the vehicle dash. We advise caution whenever your removing or handling plastic parts of a vehicles dash. **WARNING:** Unnecessary force or pressure can cause pieces to crack or break.

Logo and part number will be right side up and readable when installed.

TOOLS NEEDED: Dash Trim Tool, (Part #SIT-104), #T-20 Torx driver.

PARTS INCLUDED: One Custom Bezel Mount and Instructions.

LOCATION OF MOUNT: To the Right of the Climate Control.



Step 1.

Begin installation by removing the bezel that surrounds the climate control. There are four (4) clips that secure this bezel. Use the Dash Trim Tool (Part #SIT-104) to release this dash bezel from the clips that secure it. Set the bezel aside carefully.

Step 2.

With the bezel removed, locate and remove the two #T-20 screws from the side of the bezel that surrounds the climate control. Set these two screws aside. **Note:** See middle picture for guidance.



Step 3.

Place the **Custom Bezel Mount** over the existing screw hole, replace original factory screw, and tighten. **Carefully** reinstall the dash in reverse order securing all screws, clips and bezels. Install any **Bracketron** phone holder or **Amps** compatible device to your **Custom Bezel Mount**. Your installation is complete.



© Bracketron Inc, 2007 All rights reserved.

The information in this document is subject to change without notice. Bracketron Inc. assumes no responsibility for any errors that may appear in this document nor do we assume any liability in connection with its use. This supersedes and voids all previous literature. Literature already in circulation may not be current. Please contact the sales department for additional information.

Bracketron Inc will not be responsible or liable for damage to vehicles in the installation and or removal of this **Bracketron Inc** mount.

Bracketron Inc will not be liable for personal injuries or damage to property resulting from a motor vehicle accident and or improper installation of this **Bracketron Inc** mount.

Bracketron Inc 5249 West 73rd Street, Suite G, Edina, MN 55439, Ph: 952-746-7775 Fax: 1-800-660-1784 Toll Free: 1-866-237-4443

Web Address: www.bracketron.com